

General Catalog  
**Medical Tubes,  
Copper and Bronze  
Accessories**

## Medical Grade Copper Pipe



This tube is designed for medical gas supply equipment and vacuum installations. This is a tube especially designed for medical gas supply system equipment and for the production of vacuum installations.

It has a smooth, dry and specially clean inside surface. It surpasses the corresponding requirements of EN 13348 (seamless copper tubes for medical gases and vacuum). This specification requires, among other things, that the maximum permissible contamination of the tube's inside surface (measured as carbon) should not exceed a level of 20 mg/m<sup>2</sup>.

The tube is suitable for medical technology tube systems according to EN 737-3. Each tube is firmly sealed at both ends to ensure the inner surface remains clean until the moment tubes are installed.

## Copper and Bronze Accessories



Accessories for Hospital Networks:

